


# Polyfiber

FOR PROFESSIONAL USE ONLY

## Description

Two-pack, fiber-reinforced bodyfiller designed to fill rusted-through areas of car and commercial vehicle bodies.



100 Polyfiber  
2.5 Putty / Bodyfiller Hardener



Application time:  
12-15 minutes at 20°C




30 minutes at 20°C



Final sanding step for bodyfiller P180 - P220



Final sanding step for Featheredge P320 - P400



Recoatable with any Sikkens preparatory products  
With the exception of waterborne products.



Use suitable respiratory protection  
Akzo Nobel Car Refinishes recommends the use of a fresh air supply respirator.

Read complete TDS for detailed product information

# Polyfiber

## FOR PROFESSIONAL USE ONLY

### Description

Two-pack, fiber-reinforced bodyfiller designed to fill rusted-through areas of car and commercial vehicle bodies.

### Preparation process



Remove any surface contamination prior to sanding application using appropriate surface cleaner. Pre-clean the surface with warm water and detergent, rinse sufficiently with clean water.



Remove existing coating and sand down to the bare substrate using P180 - P220 grit as the final step. For detailed surface preparation see TDS S8.06.02



Surface cleaning, remove any surface contamination prior to putty/bodyfiller application using appropriate surface cleaner.

### Suitable substrates

Steel  
Glass Reinforced Polyester laminates


### Product and additives

Polyfiber  
Putty / Bodyfiller Hardener

### Basic raw materials

Polyfiber: Polyester resins  
Hardener: Peroxide

### Mixing



**100** Polyfiber  
**2.5** Bodyfiller hardener

Mix the bodyfiller thoroughly to a homogeneous mass (uniform colour).  
Avoid air entrapment.  
Mix the correct amount by weight (on a scale).

### Pot-life

Application time 12-15 minutes at 20°C.

# Polyfiber

## FOR PROFESSIONAL USE ONLY

### Application




Apply the polyester bodyfiller to the bare substrate by placing the spreader at a 60° angle. Avoid thick edges of bodyfiller around the perimeter of the repair by tapering away toward the original finish.

Do **not** apply Polyfiber directly to any existing finishes or directly on top of any acid containing Washprimer.

Do **not** apply Polyfiber over Primer Surfacer EP.  
Application temperature range between 15°C-35°C.

### Drying



Ready to sand after 30 minutes at 20°C.  
If force dried, the bodyfiller can be sanded after 20 minutes at 40°C.



Ready to sand after 6 minutes  
Use IR **low** power setting at a 70-100 cm distance between panel and IR unit.  
Temperature should not exceed 90°C.  
For additional infra red drying information; see TDS S9.01.01

### Sanding process



P80 - P120 - P220  
Use a guide coat between the sanding steps.



P220 - P320 (P400 for a spot repair).  
Take care to remove any coarse sanding scratches that may have been created in the feather edge area during the sanding of the bodyfiller.



Remove any surface contamination prior to primer, filler or surfacer application using appropriate surface cleaner. Where bodyfiller is exposed, avoid contact with water (e.g. waterborne degreaser).

### Recoatable with

All current Sikkens preparatory products with the exception of waterborne products.

### Cleaning of equipment

Clean the application equipment immediately after use with Sikkens Solvent or a solvent borne Gun cleaner.

### VOC

The VOC content of this product in ready to use form is max. 171 g/liter.

# Polyfiber

**FOR PROFESSIONAL USE ONLY****Product storage**

Product shelf-life is determined when products are stored unopened at 20°C.  
Avoid extreme temperature fluctuation.  
Product shelf life data see TDS S9.01.02

**Akzo Nobel Car Refinishes (Singapore) Pte Ltd**

**Address: 3 Changi Business Park Vista, #05-01 Akzo Nobel House, Singapore 486051**

**Tel: +65 6635 5262**

**FOR PROFESSIONAL USE ONLY**

**IMPORTANT NOTE** The information in this data sheet is not intended to be exhaustive and is based on the present state of our knowledge and on current laws: any person using the product for any purpose other than that specifically recommended in the technical data sheet without first obtaining written confirmation from us as to the suitability of the product for the intended purpose does so at his own risk. It is always the responsibility of the user to take all necessary steps to fulfill the demands set out in the local rules and legislation. Always read the Material Data Sheet and the Technical Data Sheet for this product if available. All advice we give or any statement made about the product by us (whether in this data sheet or otherwise) is correct to the best of our knowledge but we have no control over the quality or the condition of the substrate or the many factors affecting the use and application of the product. Therefore, unless we specifically agree in writing otherwise, we do not accept any liability whatsoever for the performance of the product or for any loss or damage arising out of the use of the product. All products supplied and technical advices given are subject to our standard terms and conditions of sale. You should request a copy of this document and review it carefully. The information contained in this data sheet is subject to modification from time to time in the light of experience and our policy of continuous development. It is the user's responsibility to verify that this data sheet is current prior to using the product.

Brand names mentioned in this data sheet are trademarks of or are licensed to Akzo Nobel.

**Head Office**

AkzoNobel Car Refinishes B.V., PO Box 3 2170 BA Sassenheim, The Netherlands. [www.sikkenscr.com](http://www.sikkenscr.com)